early learning centre SS16

sku number : 142567_142661 product : trike to scooter

pack dimensions : 297mm(H) x 210mm(W)

supplier : HYPRO FOB category : Sports & Activity date: 3 Nov 2015 designer : Gloria

colours:

	approval	date	signature
	packaging manager		
	copywriter		
	QA		
	product manager		


2 in 1 trike to scooter user guide

142567 / 142661 1115

Early Learning Centre® Watford WD24 6SH England.

Customer Service Department 0371 231 3513

twist mechanism for changing modes



T-bar assembly

step 1


With the clamp (A) fully opened and unscrewed, locate the T-BAR (B) and insert into the opening at the top of the

step 2

Insert the T-BAR fully, ensuring the pin (E) is protruding from the stem. Tighten the crank arm (D) clockwise to lock the bar in position.

scooter mode





safety first

- Warning. Protective equipment should be worn.
- Recommend to wear a helmet, knee pads, elbow pads, wrist pads and protective clothing.
- The toy shall be used with caution, since skill is required to avoid falls or collisions causing injury to the user and third parties
- \bullet Do not take this scooter on the road or public highway. Not to be used in traffic. 20kg Max.

Maintenance

• Always make sure all screws and nuts are securely tightened before every use, the self lock fixture may lose their effectiveness.

changing modes

